


KÄRCHER

makes a difference

NT Tact Te L / NT Tact Te M / NT Tact Te H

Only for Australia & New Zealand



The fuse protects the socket against overload due to overcurrent.
When it responds, a white pin becomes visible under the transparent cap.
Pushing the pin will turn the power back on.
Possibly the cause of the trip (e.g. the connected device) must be removed.